

ALIGATOR



Návod k použití / Manual

Life Tag



Lokátor s podporou Apple Find My

CZ | Návod k použití

Lokátor Aligator Life Tag slouží k ochraně vašich cenností před ztrátou nebo krádeží. Pomocí služby Apple Find My můžete kdykoli snadno určit jeho polohu.

Zapnutí a vypnutí lokátoru

Pro zapnutí stiskněte jednou tlačítko lokátoru, dokud se neozve dlouhé pípnutí – zapnuto.

Pro vypnutí přidržte tlačítko stisknuté po dobu cca 3 sek. Ozvou se 2 pípnutí pro potvrzení vypnutí lokátoru.



Přidání lokátoru do aplikace


Spusťte aplikaci **Najít** (Find My) ve vašem iPhone nebo iPadu, ťukněte na ikonu „**Předměty**“, dále na ikonu „**+**“ a zvolte „**Přidat jiný předmět**“. V seznamu nalezených zařízení zvolte zapnutý lokátor a potvrďte „**Připojit**“. Následně postupujte podle pokynů na obrazovce.

Reset a obnovení nastavení

Nejprve v aplikaci **Najít** (Find My) odeberte lokátor ze seznamu vašich zařízení, pak 5× rychle stiskněte tlačítko na lokátoru a při pátém stisku ho přidržte, dokud se nezve pípnutí.

Výměna baterie

Lokátor je napájen jednou baterií CR2032 s výdrží až jeden rok. Pro výměnu baterie sejměte zadní stranu lokátoru a vyměňte baterii. Symbol + na baterii musí být nahoře:



Obsah balení

- Lokátor Aligator Lifemate Life Tag
- Kroužek na klíč a poutko
- Návod k použití

Technické specifikace

- Aligator Lifemate Life Tag HD-P16-3
- Voděodolnost: IPX65
- Materiál: PC + ABS
- Připojení: Bluetooth BLE 5.2

Bezpečnost a ekologie



Vysloužilý výrobek nikdy nevyhazujte do běžného komunálního odpadu – může obsahovat látky **nebezpečné pro životní prostředí!!!** Po ukončení používání musí být předán na příslušné sběrné místo, kde zajistí jeho recyklaci či ekologickou likvidaci.

Baterie vložená do výrobku nepatří do běžného komunálního odpadu!!! Může obsahovat látky, škodlivé životnímu prostředí. Baterii odevzdejte na příslušném sběrném místě, kde zajistí její ekologickou likvidaci.

Informujte se u svého prodejce či na obecním úřadě, kde se příslušná sběrná místa nachází, příp. jak zacházet s použitým výrobkem a baterií. Popř. je můžete odevzdat přímo prodejci nebo na některé z poboček ADART COMPUTERS s.r.o. Baterii nevhazujte do ohně ani ji nevystavujte teplotám nad +60°C hrozí nebezpečí výbuchu či požáru.

Nedodržování výše uvedených pokynů je nezákonné.

Prohlášení o shodě

Tímto ADART COMPUTERS s.r.o. prohlašuje, že typ rádiového zařízení HD-P16-3 je v souladu se směrnicí 2014/53/EU. Úplné znění EU prohlášení o shodě je k dispozici na těchto internetových stránkách:

www.aligator.cz

CZ | Toto zařízení je určeno pro použití v zemích EU.
Copyright © ADART COMPUTERS s.r.o.
Čimická 717/34 | 182 00 Praha 8 | CZ



EN | This device is intended for use in EU countries.
Copyright © ADART COMPUTERS s.r.o.
Čimická 717/34 | 182 00 Prague 8 | CZ



Manuals SK, DE, PL, HU

Stiahnutie návodu:

Handbuch herunterladen:

Instrukcja obsługi do pobrania:

Kézikönyv letöltése:



www.aligator.cz/aligator_life_tag

EN | Instructions for use

The Aligator Life Tag locator is designed to protect your valuables from loss or theft. With Apple Find My, you can easily pinpoint its location at any time.

Turn the locator On and Off

To turn on, press the locator button once until a long beep sounds.

To turn it off hold the button down for about 3 seconds. There will be 2 beeps to confirm that the locator has been switched off.



Adding the locator to the application


Launch the **Find My** app on your iPhone or iPad, tap the „**Items**“ icon, then the „**+**“ icon and select „**Add Other item**“. In the list of found devices, select the enabled locator and confirm „**Connect**“ and follow the on-screen instructions.

Reset and restore settings

First, in the **Find My** app, remove the locator from your device list. Next, quickly press the button on the locator 5 times and hold it down on the fifth press until you hear a beep.

Replacing the battery

The locator is powered by a single CR2032 battery that lasts up to one year. To change the battery, remove the back of the locator and replace the battery. The + symbol on the battery must be at the top:



Package Contents

- Alligator Lifemate Life Tag Locator
- Key ring and loop
- Instructions for use

Technical Specifications

- Alligator Lifemate Life Tag HD-P16-3
- Waterproof: IPX65
- Material: PC + ABS
- Connectivity: Bluetooth BLE 5.2

Safety and Ecology



Never dispose of an end-of-life product in normal municipal waste – it may contain substances **hazardous to the environment!!!** After use, it must be taken to an appropriate collection point for recycling or environmentally friendly disposal.

The battery inserted in the product does not belong in normal municipal waste!!! It may contain substances harmful to the environment. Take the battery to the appropriate collection point for environmentally friendly disposal.

Check with your dealer or local authority where the relevant collection points are located and how to dispose of the used product and battery. Alternatively, you can hand them over directly to the dealer or to one of the ADART COMPUTERS s.r.o. branches. Do not throw the battery into a fire or expose it to temperatures above +60°C, there is a risk of explosion or fire.

Failure to follow the above instructions is illegal.

Declaration of Conformity

ADART COMPUTERS Ltd. hereby declares that the radio type HD-P16-3 complies with Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available on the following website:

www.aligator.cz